
# NewStar user's Manual

LCD Monitor Arm FPMA-D1010.FPMA-D1020.FPMA-D1030





www.NewStar.nl Phone: + 31 (0) 23 547 88 88


## **Check-List**

01


To mount your flat panel monitor or any parts at an ergonomically correct position, start at step 1 and continue as directed.


Part Check-List

**FPMA-D1030** 












FPMA-D1020







Fitting/Tools Check-List




Clamp Check-List




### **LCD Monitor Arm**



## **Assembly Guide**




desk thickness over 70mm, please adjust screws with 5mm Allen Key. (as figure a.)




#### "Pole" assembly step

Fix the clamp on the desk, use 4mm Allen key to secure the pole and clamp with 4 screws. Then put the plastic cover through the pole and check the pin position with the screw together.(as figure b.)





Adhere






(1)Please loosen the knob at frist, and then apart the fixing lump.(2)Then,take VESA up .If it is difficult to take it up, you can take it by knocking slightly(as figure. C).





#### Step 4


Insert the arm into the pole. Adjust the level of high to the most comfortable view.





**Assembly Guide** 

#### Step 5

Use the lever tighen the arm(as figure D.) or secure it with one screw(as figure E.) and then put in the plug.










05


# Cautions


06


















Place LCD with facing downward on flat surface. Place VESA on the LCD back as figure and align to the screw holes. Secure them together with four screws .And then tighten them up with screwdriver(not provided).



75mmx75mm 100mmx100mm VESA interface.

#### Step 7

